


## Programming the Remote



You can program the **VOLUME** and **MUTE** buttons on the Kaleidescape Remote to control the volume on your TV or other audio device.

**1** Press and hold the **INFO** and **PAUSE** buttons at the same time. When the indicator light at the top of the remote begins blinking, release the buttons. The indicator light stays on. The Kaleidescape Remote is now in learning mode.

**2** Place a remote that can already control the volume flat on a table with the Kaleidescape Remote 6 inches (15 cm) away.



**3** The following steps have to be repeated for the **MUTE** button and both **VOLUME** buttons.

- Check that the indicator light is still on. If it is off, repeat Step 1.
- Press and release the button on the Kaleidescape Remote for the function you want to program.
- Press and hold the button for the same function on the remote that can already control the volume for two seconds.
- The indicator light on the Kaleidescape Remote blinks twice to indicate success. If the indicator light blinks four times, try again.

**4** When finished, press the **OK** button on the Kaleidescape Remote. The indicator light blinks twice to confirm programming is complete.

## Other Resources and Support

### Browser Interface

Use the browser interface to customize your system from your computer at home. Manage movie and music libraries, even synchronize your music to iTunes.

To access the browser interface, enter one of the following URLs:

<http://my-kaleidescape> (Windows)

<http://my-kaleidescape.local> (Mac)

For more information, go to [www.kaleidescape.com/browser-interface](http://www.kaleidescape.com/browser-interface).

### Loan Program

If you have a DVD or CD that the Kaleidescape System does not recognize, you can send Kaleidescape the disc for processing. For more information, go to [www.kaleidescape.com/loan](http://www.kaleidescape.com/loan).

### Support and Documentation

For more information, go to [www.kaleidescape.com/support](http://www.kaleidescape.com/support).

For how-to videos, go to [www.kaleidescape.com/videos](http://www.kaleidescape.com/videos).

For more assistance, contact Kaleidescape Support.

- Send an email message to [support@kaleidescape.com](mailto:support@kaleidescape.com).
- Call the support line at +1 (650) 625-6160.

Copyright © 2010 Kaleidescape, Inc. All rights reserved. Kaleidescape and the Kaleidescape logo are trademarks of Kaleidescape, Inc. and are registered in the United States and certain other jurisdictions. iTunes and Mac are trademarks of Apple Inc. Other trademarks and trade names are owned by third parties and may be registered in some jurisdictions.

Kaleidescape Part No. 101-0085-00 Rev B



kaleidescape

## The Kaleidescape System Using the Remote



## Using the Remote



### 1 Turn on the Kaleidescape System

Press the **POWER** button.

### 2 Select Movies or Music

Press the **MOVIES** or **MUSIC** button to cycle through views.

Movies



Music

### 3 Select a Title

Use the **ARROW** buttons to find and select a title.


**Tip:** Use the **PAGE** buttons to scroll by page.

### 4 Play It

Press the **PLAY** button to play a movie or music title.

## Views

- **List View** Use the **UP/DOWN ARROW** buttons to navigate through movies or music. To sort, use the **LEFT/RIGHT ARROW** buttons to select a column and press the **OK** button.
- **Covers View** Use the **ARROW** buttons to highlight a movie or album. If you pause on a particular cover, covers shuffle to show related titles. Press the **OK** button for movie or music details.
- **Collections View** Use the **LEFT/RIGHT ARROW** buttons to select a collection; use the **UP/DOWN ARROW** buttons to navigate through items. Press the **OK** button to select an item.



List View

Covers View

Collections View

## Kaleidescape Menu

Press the **MENU** button to select a Movie or Music view, access the details page for the disc in the tray, or view summary information about your system.

- **Disc in Tray** Any DVD or CD can be played without importing the disc. Press the **PLAY** button to start the movie or music directly.
- **System** Selecting **SYSTEM** provides information about content and disk space, serial number, software version, and status of any imports.



## Movie Overlay

When watching a movie, press the **INFO** button to view the **STATUS** of current movie chapter and remaining runtime. Then use the **ARROW** and **OK** buttons to access other playback options.

- Audio
- Subtitles
- Navigation shortcuts
- Creating favorite scenes



## Parental Control

Press **MENU** button and select the **Movies** tab, then select Parental Control.

Or press a **NUMBER** button on the Kaleidescape Remote to enter a parental control passcode for movies.



## Music Now Playing

Use the **ARROW** and **OK** buttons to control the **REPEAT** and **RANDOM** options. Use the **ARROW** buttons to select a song from the **NOW PLAYING** list. Press the **PLAY** button to jump to a song or the **OK** button to view album details.

